

## ODB - Mode 6 Data

### CR4x

| MID (hex) | TID (hex) | UID (hex) | Description                                         |
|-----------|-----------|-----------|-----------------------------------------------------|
| 01        | 83        | 30        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 1        |
| 01        | 91        | 11        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 1        |
| 01        | 92        | 11        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 1        |
| 01        | 93        | 11        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 1        |
| 02        | 83        | 30        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 2        |
| 02        | 92        | 11        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 2        |
| 02        | 93        | 11        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 2        |
| 02        | D1        | 84        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 2        |
| 02        | D2        | 11        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 2        |
| 02        | D4        | 87        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 2        |
| 02        | D5        | 87        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 2        |
| 02        | D9        | 84        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 2        |
| 03        | 83        | 30        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 3        |
| 03        | D1        | 84        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 3        |
| 03        | D2        | 11        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 3        |
| 03        | D4        | 87        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 3        |
| 03        | D5        | 87        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 3        |
| 03        | D9        | 84        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 3        |
| 04        | E6        | 41        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 4        |
| 04        | E7        | 41        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 4        |
| 04        | E8        | 2F        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 4        |
| 04        | E9        | 2F        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 4        |
| 04        | EA        | 96        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 4        |
| 04        | EB        | 96        | Exhaust Gas Sensor Monitor Bank 1 - Sensor 4        |
| 21        | 90        | AF        | Catalyst Monitor Bank 1                             |
| 31        | 97        | 06        | EGR Monitor Bank 1                                  |
| 31        | 98        | AF        | EGR Monitor Bank 1                                  |
| 31        | 99        | AF        | EGR Monitor Bank 1                                  |
| 41        | 81        | 8B        | Exhaust Gas Sensor Heater Monitor Bank 1 - Sensor 1 |
| 44        | EC        | 13        | Exhaust Gas Sensor Heater Monitor Bank 1 - Sensor 4 |
| 81        | A1        | 3C        | Fuel System Monitor Bank 1                          |
| 81        | A2        | 3C        | Fuel System Monitor Bank 1                          |
| 81        | A3        | 3C        | Fuel System Monitor Bank 1                          |
| 81        | A4        | 3C        | Fuel System Monitor Bank 1                          |
| 85        | 97        | 06        | Boost Pressure Control Monitor Bank 1               |
| 85        | 9A        | 30        | Boost Pressure Control Monitor Bank 1               |
| 98        | 85        | 84        | NOx Catalyst Monitor Bank 1                         |
| 98        | B1        | 84        | NOx Catalyst Monitor Bank 1                         |
| A2        | 0B        | 24        | Misfire Cylinder 1 Data                             |
| A2        | 0C        | 24        | Misfire Cylinder 1 Data                             |
| A3        | 0B        | 24        | Misfire Cylinder 2 Data                             |
| A3        | 0C        | 24        | Misfire Cylinder 2 Data                             |
| A4        | 0B        | 24        | Misfire Cylinder 3 Data                             |

|    |    |    |                          |
|----|----|----|--------------------------|
| A4 | 0C | 24 | Misfire Cylinder 3 Data  |
| A5 | 0B | 24 | Misfire Cylinder 4 Data  |
| A5 | 0C | 24 | Misfire Cylinder 4 Data  |
| B2 | 85 | 17 | PM Filter Monitor Bank 1 |
| B2 | C3 | 36 | PM Filter Monitor Bank 1 |
| B2 | C4 | 36 | PM Filter Monitor Bank 1 |
| B2 | C5 | 04 | PM Filter Monitor Bank 1 |